

ELECTRIC PRUNING SHEARS

—— Instruction for use ——

AGRO
FORCE

PROTECH
299S



SK-5
CARBON
STEEL

BRUSHLESS

Contents

Packing Lis	2
Product Overview	3
Instruction	3
Performance Description	3
Technical Parameters	3
Part Name and Diagram	4
Utilization and Maintenance	5
Start	5
Tips	5
Battery Charging	5
Attentions	5
Blade Polishing	6
Blade Replacement	6
Maintenance Attentions	7
Maintenance Attentions of Electric Pruning Shears	7
Maintenance Attentions of Batteries	7
Safety Attentions	8
Site Safety Description	8
Electric Safety Description	8
Personnel Safety Description	8
Abnormalities and Disposal	9
After-sales Services	10
Statements	10

Dear users, thank you for high-quality products of the company! In order to better use the products, please read the manual before using and remain it for checking. If there is any problem in using process, please contact with us in time. Our professionals will answer questions to you and wish you to use it happily!

► PACKING LIST

● TOOL CASE



● The tool case includes the following accessories:





! Note: whether the body with LCD Screen depends on the model of the product you buy

1. Electric pruning shears
2. Lithium batteries
3. Charger
4. Kit
Lubricating oil
Grindstone



- The products are only limited to be used by professionals. Quality guarantee of non-human damage will be one year.
- The final power of interpretation of products is owned by the company

▶ Product Overview



● Instruction

1. Please read the manual carefully.
2. It only can be charged indoor.
3. With double insulation, it has no need for ground connection.
4. There is a fault security transformer.
5. As overheating charging, it will realize automatic power off.
6. Don't dispose chargers with domestic waste materials.
7. Don't dispose batteries with domestic waste materials.

● Performance Description

The products are battery-driven electric pruning shears and are composed of a fixed blade, a movable blade, a lithium battery, a charger, a tool case etc. The charging voltage is AC 110V-240V. The products are mainly used for shearing fruit branch grafting, shearing and picking up in lots of orchards, etc. It is convenient and easy to use. The branch shearing quality is significantly higher than traditional manual shears.

● Technical Parameters

Basic Information of Electric Pruning Shears	
Working voltage	DC 14.4V
Weight	0.9kg
Battery	14.4V, 2.6A
Working voltage of the charger Input	AC 110V-240V
Battery charging time	1-1.5h
Battery working time	3-4h

Shearing Range(Maximal Size)	
Diameter	28mm
Working temperature	-10°C-65°C



Please read all safety warnings and instructions carefully; Electric shock, fire hazard and serious burning may take place for violating relevant warnings and instructions.



Don't use or expose electric pruning shears in the rain.



As operating electric pruning shears, don't close the shearing areas by hands, for fear of damage.

● Part Name and Diagram



1. Moving blade
2. Shim
3. Dowel
4. Trigger
5. Lithium battery
6. Digital display screen
7. Charger
8. Power switch

⚠ Note: whether the body with LCD Screen depends on the model of the product you buy



► Maintenance Attentions

● Maintenance Attentions of Electric Pruning Shears

1. Don't shear off the branch out of the shearing range; don't shear off non-plant materials, such as metals and stones, etc; don't use a vice clamp to clamp tools; please replace a shear blade, if it is worn or damaged;
2. Please maintain equipment cleanness, clean electric pruning shears, batteries and chargers with a clean cloth as cleanness(don't use any corrosive or solvent detergents) and please a soft brush or a dried cloth to clean dust on top shears;
3. Don't soak electric pruning shears, batteries and chargers in water or any other liquids;
4. Please use equipment correctly as instruments; please stop using it when there is any damage in electric pruning shears, batteries and chargers, etc.
5. If the switch can't be connected normally or turn off electric pruning shears, don't use the electric pruning shears. It will be dangerous to control electric pruning shears without switch and it must place under repair;
6. Please ensure that switch is kept in the power off state as replacing accessories or storing electric pruning shears. Such a preventive measure will reduce the risk of launching electric pruning shears accidentally.
7. Please turn off the blade of the idle electric pruning shears and store it out of the children's contact. It is dangerous to let inexperienced person and untrained users to operate the electric pruning shears.
8. As using the electric pruning shears, please abide by instruments and usage, and consider working environment and tasks; it may cause a risk by using electric pruning shears for unconformable operation.
9. After it is used, please remove dirty on the moving blade and shim, add lubricating oil or engine oil on the contact part, make the blade keep in the normal maintenance state and reduce and extend blade lifetime for next use.

● Maintenance Attentions of Batterie

1. Don't charge under the environment below 0°C and below 45°C; this may damage batteries and chargers.
2. Please ensure that switch is off before connecting to batteries; under the circumstance of switch opening, it may cause an accident as connecting batteries to electric pruning shears.
3. Only use the chargers assigned by the manufacturer to charge batteries; chargers with unmatched batteries may cause a fire hazard as charging
4. When batteries are unused, please make it get away from tiny metal objects, such as clips, coins, keys, nails, and screws, which may shorten the lifetime. Battery short circuit may cause burning or fire hazard.
5. Don't disassemble or reconstruct batteries
6. Don't use short-circuit batteries.
7. Don't use it around heat source
8. Don't put batteries in fire or water
9. Don't charge closing to fire or under sunshine
10. Don't insert nails into batteries, don't impact batteries with hammer or by trampling or don't throw batteries
11. Don't use seriously damaged or distorted batteries
12. Don't weld batteries directly
13. Don't charge batteries reversely, connect in antipole or discharge excessively
14. Don't connect batteries to the recharge socket or vehicle cigar lighter socket.

15. Don't use it on the non-assigned equipment
16. Don't contact with lithium batteries directly
17. Don't put batteries in high-temperature and high-pressure containers, such as microwave ovens, etc.
18. Don't use weeping batteries
19. Don't let children contact with batteries
20. Don't use or place batteries under the direct sunshine(or in cars under direct sunshine); otherwise, it may cause overheating and burning batteries to cause invalid functions and shorten lifetime
21. Don't use batteries in static(exceeding 64V) sites
22. As batteries are used for the first time, don't use and send to the selling site, if there is corrosion, unpleasant smell or abnormal phenomenon
23. If there are EH batteries on skin or clothing, please rinse with clean water
24. If electric pruning shears are not used for a long time, please charge it fully for reserve

► Safety Attentions

Warning! Please read all instructions carefully. If not, it may cause electric shock, fire or other serious damage!

● Site Safety Description

1. Please remain clean and brightness in workplaces. Chaotic and dark workplaces may cause an accident.
2. Don't operate electric pruning shears in the explosive, inflammable and humid environment;
3. After children and audiences leave, operate electric pruning shears normally, for fear that distraction in operation may cause accident damage.

● Electric Safety Description

1. The battery socket of electric pruning shears must be matched with battery connecting plug. Don't refit socket and plug in any way.
2. Don't expose electric pruning shears in the rain or humid environment. Water or other liquids may increase electric shock danger or damage electric appliances
3. Don't abuse electric wires; don't use power lines to lift and pull electric pruning shears or pull out the plug; let electric pruning shears keep away from heating, oil, sharp edge or moving parts; don't use chargers when power lines or plugs are damaged. Damaged and twined wires will increase risk of electric shock.

● Personnel Safety Description

1. Keep guard: When operating electric pruning shears, concern the operation and keep guard; don't operate electric pruning shears as being tired, drug therapy or alcohol response; during the operation period, energetic distraction may result in serious personal damage.
2. Use safety devices, always wear goggles, dusk mask, anti-skid safety shoes and safety helmet and listening protective devices under the suitable conditions to reduce personal damage

3. Before connecting to electric pruning shears, take away all adjustable keys or wrenches; wrenches or keys left on the rotating parts of electric pruning shears may result in personal damage.
4. As operation, don't stretch hands too long; hands should get away from shearing areas; as shearing, don't put hands under materials for any reason; ensure that any material or surface under the shearing areas won't be damaged by shearing blades; and concern underfoot and body balance so as to better control electric pruning shears under the accident situations;
5. Dress suitably; don't wear loose clothing or wear accessories, let your hair, clothing and sleeves get away from moving parts; loose clothing, accessories or long hair may be involved in moving parts.

● Abnormalities and Disposal

1. When non-shearing articles are put in the incision, loosen the trigger immediately; moving blade will return to the opening state automatically.
2. When branches are too hard, please release the trigger timely and moving blade will return to the opening state automatically.
3. When batteries can't be charged normally, please firstly check whether the charger is the attached in the product; secondly, check whether the charging voltage is consistent with the nameplate voltage.
4. If there are electric or mechanical faults, please close the switch immediately.
5. Without abiding by the operating instruments, batteries may erupt liquid; don't contact the liquid; if it is contacted accidentally, rinse it with clean water; if the liquid is splashed into eyes, please see a doctor immediately in addition to rinse with clean water; liquid erupted from batteries may result in stimulation or burning

► After-sales Services

If you have any question in using process, please contact with us timely(see below for contact information); we have professionals to solve questions for you. Qualified servicemen use identical replacers to maintain electric pruning shears and this may maintain safety performance of electric pruning shears.

► Statement

The company remains the right to do technical improvement on products described in the instrument. If there is any change, please understand it. If there is any difference between images or texts in the instrument and material objects, please refer to material objects.